


MU-2-R Setup disk manual

First read the Operation Guide of the kit you are using



■ MU-2-R Series Product List (as of Mar. 2009)

Product number	Product name
1. MU-2-R	Embedded low power radio modem
2. MU2-RIK	MU-2 RS232C Interface Kit
3. MU2-UIK	MU-2 USB Interface Kit

■ Main Contents of the Setup Disk

◆ Operation Guides

1. MU-2 Operation Guide
2. MU-2 RS232C Interface Kit Operation Guide
3. MU-2 USB Interface Kit Operation Guide
4. MU-2 Evaluation Software Program Operation Guide

◆ Software program

1. MU-2 Evaluation Software Program (MU2-ESP)
2. Operation Guide Access Program
3. Setup Launcher

◆ Drivers and installers

1. USB driver

■ System Requirements

The operating environment for the setup disk and MU-2-R related programs is as follows.

1. OS: Windows Vista, Windows XP, Windows 2000
2. Recommended CPU operating speed: 400 MHz or higher
3. Recommended display: 1,024 x 768 pixels or higher
4. Hard disk capacity: 5 MB or more
5. Web browser: Explorer 5.01 or higher

■ How to Set Up MU-2-R Series Products & the Operation Guide Access Program

The CD-ROM contains a launcher for setting up your computer with drivers and installers for MU-2-R related products. When you insert the CD-ROM in your computer, a menu appears automatically after a short interval. With the Operation Guide access program you can view all the Operation Guides for MU-2-R series products.

◆ Precautions for setup

☞ Note

1. First mount the MU-2-R on the interface board included in the kit you are using. When mounting the module, refer to the cautions in the Operation Guide of the kit.
2. The procedures for installing the drivers and installers of the MU-2-R series products relate to Windows XP. When performing an installation in other versions of Windows, please note that the procedures and dialogs displayed may differ.
3. Always close other applications before installing drivers or installers.

◆ Items required for setup

☞ Important


In order to run the Operation Guide access program and the setup launcher for MU-2-R series products, Adobe Reader must be installed.

If the software is not already installed, install it from the following web sites.

You can go to these web sites using the menu buttons on the setup disk launcher.

1. Adobe Reader
<http://www.adobe.co.jp/products/acrobat/readermain.html/>

◆ Setup disk launcher



1. By clicking the "Operation guide" button, you can access the documentation files for the MU-2-R series products.
2. By clicking the "Setup launcher" button, you can set up the drivers, installers and so on required for using the MU-2-R series products.
3. You can install the Adobe Reader from the respective web sites.
4. The name of the execution file of the launcher is as follows.
Launcher1.exe (in the CD-ROM root directory)


◆ Operation Guide access program



1. When you roll your cursor over each button, a button for the relevant Operation Guide appears. Click the button to read the Guide with Adobe Reader.

2. Execution file name
EManual.exe (in the CD-ROM root directory)

◆ Setup program for MU-2-R series products



Here you can set up the drivers and installers required for each product. Before starting the installation, be sure to click the "About..." button to gain an understanding of the installation method.

1. Installation of the MU-2 Evaluation Program
2. Installation of the drivers for the MU-2 USB interface board
3. The name of the execution file of the launcher is as follows.
Launcher2.exe (in the CD-ROM root directory)

■ Enquiries and Web Site

Please use any of the following methods to contact Circuit Design.
Also visit our web site for technical information, up-to-date information, FAQs and so on.

- ✎ : E-mail is convenient for most enquiries that require a quick response.
- ✎ : For technical enquiries, please provide specific information about the development environment and the problem you are experiencing.

- ◆ **e-mail:** info@circuitdesign.jp
- ◆ **TEL:** +81+(0)263-82-1024
- ◆ **FAX:** +81+(0)263-82-1016
- ◆ **Post** 7557-1 Hotaka, Azumino-city, Nagano 399-8303 JAPAN
- ◆ **Web site:** http://www.circuitdesign.jp